



Natures Composites

Premium Sustainable Fencing

6' Shadow Box Fence Installation Guideline

Before You Begin

1. Verify Location of Underground Utilities
2. Locate Property Lines
3. Consult Local Regional Building Codes
4. Always Wear Appropriate Safety Equipment
5. Standard Woodworking Tools May Be Used



Post Installation

1. Dig 12" Diameter Hole 24" -36" Deep Depending on Local Building Codes (Detail A)
2. Add 2" of Gravel to Bottom of Holes
3. Set Posts in Minimum 24" of Concrete
4. Before Concrete Sets, Plumb and Level Posts Making Sure to Use a Stringline to Maintain Alignment
5. Allow Concrete to Properly Set Before Proceeding

Picket Installation

1. After Posts Are Set, Fasten (3-4) Cross Rails To The Post (See Detail B)
 - Recommend 4 Rails for 6' Post
2. Fasten First Picket 1/8" from the Post With (2) Composite Screws for Each Rail.
 - Offset Fasteners as Shown In Detail C
 - Elevate Pickets 1-2" Off the Ground
3. Install Next Picket on Opposite Side with Desired Spacing, Continue the Alternating Pattern Over Remaining Area
4. Finish by Installing Post Caps. Use Small Screws and Pre-Drill Pilot Holes Using Minimal Torque

Note: If Deflection Occurs Add Additional Cross Rails



For More Information, Please Visit
<https://www.naturescomposites.com>